


Connect your Chromebook to Wi-Fi


To connect to the Internet, use a compatible Wi-Fi network.

Step 1: Turn on Wi-Fi


1. At the bottom right, select the time.
2. Select Not Connected .
Note: If you see your Wi-Fi network name and a signal strength, your Chromebook is already connected to Wi-Fi.
3. Turn on Wi-Fi.
4. Your Chromebook will automatically look for available networks and show them to you in a list.

Step 2: Pick a network and connect

Connect to an open network


1. Select the Wi-Fi network .
2. Remember, your information might be visible to other people on this network.

Connect to a secure network

1. Select the secure Wi-Fi network .
2. Type the network password.
3. Select Connect.

Connect to an unlisted network

Administrators may hide networks so only certain people can use them. To connect to an unlisted network:

1. Select Join other network .
2. Enter the network information in the box that appears.
3. Select Connect.

Information for this network is automatically saved so you can connect automatically later.